

PORT1			PORT2		
GND	GND	VDD			
P2.9-R7	P2.8-R6	P4.9-A9	VDD	GND	GND
P2.7-R5	P3.16	P4.10-A10	P0.16-SSEL	P0.15-SCK	P4.23
P4.27-LED2	P2.5-HSYNC	P2.6-R4	P4.8-A8	P0.18-MOSI	P0.17-MISO
P3.17	P2.3-VSYNC	P2.4-ENB	P4.22	P4.7-A7	P0.19
P1.13	P4.12-A12	P4.11-A11	P0.20	P0.21	P4.26-LED1
P3.18-PD	P2.1	P2.2-DCLK	P0.22	P4.6-A6	P4.21-A21
P2.0	P4.13-A13	P1.7-MCIDAT1	P4.19-A19	P4.20-A20	P2.10-ISP
P1.12-MCIDAT3	P0.9-B1	P1.5-MCIPWR	P2.11-INT	P.212-B2	P4.5-A5
P0.8-B0	P3.19	P4.14-A14	P4.18-A18	P4.4-A4	P4.17-A17
P1.11-MCIDAT2	P0.6-G0	P0.7-G1	P2.13-B3	P0.11-RXD2	P4.16-A16
P3.20	P0.4-R0	P0.5-R1	P2.15	P4.3-A3	P0.10-TXD2
P1.6-MCIDAT0	P4.15-A15	P4.28-R2	P0.1-TD1	P0.0-RD1	P2.17-~RAS
P4.29-R3	P1.3-MCICMD	P3.21	P1.29-B7	P1.28-B6	P2.14
P4.25-~WE	P1.16-ENET_MD C	P1.17-ENET_MDI O	P1.27-B5	P2.22	P2.16-~CAS
P4.24-~OE	P1.14-ENET_RX_ER	P1.15-ENET_REF_CLK	P4.2-A2	P2.21	P1.26-B4
P1.10-ENET_RXD1	P4.30-~CS0	P1.2-MCICLK	P1.25-G7	P1.24-G6	P4.1-A1
P1.8-ENET_CRSDV	P3.8-D8	P1.9-ENET_RXD0	P1.23-G5	P1.22-G4	P4.0-A0
P4.31	P1.1-ENET_TXD1	P1.4-ENET_TX_EN	P2.20-~DYCS0	P1.20-G2	P1.21-G3
P1.0-ENET_TXD0	P3.0-D0	P3.22	P0.14-USBHSTN2	P2.19	P1.19-USBPPWR1
P3.1-D1	P0.2-TXD0	P3.9-D9	P1.18-USBUPLED1	P2.23	P3.23-LED3
P0.3-RXD0	P3.10-D10	P3.27	P0.30-USB_D-1	P2.18-CLKOUT0	P0.29-USB_D+1

PORT1			PORT2		
P3.2-D2	P3.11-D11	RTCK	P3.24-ADJ	P3.25	P2.26
TDO	P3.3-D3	P3.12-D12	P3.26	P2.24-CKEOUT0	P2.25
P3.28-Y2	TMS	TDI	USB_D-2	P0.27	P0.31-USB_D+2
~TRST	VBAT	P3.13-D13	P2.28-DQMOUT0	P2.27	P0.28
P3.29-X2	P0.26-AD03	TCK	P0.13-USBUPLED2	P1.30-USBPWRD2	P2.29-DQMOUT1
P0.25	P0.24-AD01	P3.4-D4	P0.12-USBPPWR2	P2.31	P1.31-USBOVRCR2
P0.23	P3.30-PINOVRCR1	P3.5-D5	ALARM	P2.30	~RESET
P3.6-D6	P3.31-PINHSTN1	P3.14-D14	~RSTOUT	P3.7-D7	P3.15-D15
GND	D5.0V	VDD	VDD	D5.0V	GND